FLARE

DISPOSABLE DEVICE



USER MANUAL

















USB-C Port

SPECIFICATIONS

Commercial Name: FLARE HIS Brand Name: FLARE Model Name: HIS Product Dimension: L52xW28xH92mm Product Type: Dienogable Davise

Frouct Unimension: LozxWz8xH9Zmm
Product Type: Disposable Device
Ingredients: Propylene Glycol, Vegetable Glycerin,
Natural & Artificial flavors and Conventional Freebase
Nicotine
Nicotine Content: 120mg Conventional Freebase
Nicotine

Nicotine Concentration: 12mg/mL Conventional

Volume: 10mL E-liquid
Coil Resistance: 1.0ohn
Food Allergen(s): N/A
Alcohol Content: N/A Capacity: 800mAh Type: Rechargeable Battery

Port: Type C

Minimum resistance: 0.5ohm Maximum voltage: 3.35V Watts: Low-power 11W, High-power 22W

Charging Voltage: 5V Discharge Voltage: 3.3-4.0V Charging Current: 450±50mA Tank Material: PCTG

Device Hardware Materials: Silicone,PC, ABS+PC, SUS304 stainless steel, iron chromium aluminum, Glass fiber, polymer cotton, EVA, 3M glue.

Manufactured by: INFINITE-N TECHNOLOGY LIMITED Address: No. 9, He Wang 2nd Road, Floors 1, 2, and Sha Tou Community, Sha Jing Street, Bao'an District, Shenzhen

License: 5144030058

Importer: APEX PACIFIC CORPORATION Address: 846 Warehouse KLM West Service Road, Marcelo Green Village Parañaque City 1700 Assessment Number: A9-(I)-05-24-03473

Manufacturing Date: 09052024 Best By Date: 09052026 Batch No.: FLXHI09052024 Website: www.apexcorp.online

INSTRUCTION:

How to use:

 Deactivate: Press the boost button 3 times within 2 seconds. The screen will flash 3 times and then turn off. The device will be locked and unable to draw smoke. Activate: Press the boost button 3 times within 2 seconds. The screen will flash once, indicating the device is unlocked and ready for use.

 Place the mouthniece between your lins. Inhale slowly to activate the device automatically.
 Usage to be avoided:

Avoid exposing the device to extreme heat or direct sunlight, as this can cause leakage or flavor changes.

Keep the device away from water or liquids to prevent malfunctions and short circuits.

HANDLING & MAINTENANCE:

Storage: Please store the product in a cool dry place. Keep away from direct sunlight and extreme

Cleaning: Use a dry cloth or paper towel to clean the mouthpiece and other accessible parts of the device

Waste Disposal:

Waste Disposal:
Battery Removal and Disposal:
If the device contains e-liquid, place it in a sealed container or plastic bag to prevent leakage before disposal. Do not attempt to open the device or remove any remaining e-liquid.
If the device has a non-detachable battery, do not attempt to detach it.
Dispose of the entire device at an electronic waste recycling facility or collection point that accepts both e-waste and batteries.
Never dispose of the device in household trash, as it may contain hazardous materials.
If recycling is unavailable, follow local regulations for proper electronic waste disposal.

INFORMATION on OPENING, RECHARGING, AND

OPENING:

 Carefully remove the device from the packaging. remove silicon from the mouthpiece and the sticker covering the airflow at the bottom of the device.

•Check for any damage. If you find any, do not use the device and contact customer support. RECHARGING:

A Type-C charger is needed to connect to a power source before charging.

REFILLING: Product is not refillable.

WARNING:

HEALTH WARNING: This product is harmful and contains nicotine which is a highly addictive substance. It is not recommended for use by nonsmokers.

This product is not recommended for pregnant women or people with cardiovascular problems. Using this product may damage the cardiovascular system and respiratory

system, and may also lead to nicotine addiction. Do not wallow, keep out of reach of children, avoid prolonged

IF SWALLOWED: Seek medical attention immediately. IF ON SKIN: Rinse thoroughly with soap and water. IF SKIN IRRITATION OCCURS: Seek medical advice or

AGE RESTRICTION: Not for persons below 18 years old. Keep away from children and pets.

CHARGING: Only use the recommended charger. Avoid using chargers with different voltage or current specifications, as this can cause overheating, damage, or safety risks. Chargers with different characteristics should not be used.

OVERHEATING: If the vapor product system becomes too hot during use or charging, stop immediately. Do not use the device in hot environments, and allow it to cool

This product may cause undesirable effects for both users and those around them. Please use it responsibly.

Potential adverse effects for the vaper and the

persons in his/her entourage:
First-time e-cigarette users may experience mouth
irritation, dry throat, or cough. If these symptoms persist
beyond 48 hours or worsen, consult a doctor and report
the incident. Using a nicotine strength that's too low may
cause withdrawal effects such as irritability, anxiety, cause willurawal effects such as irritability, anxiety, restlessness, increased appetite, or sleep disturbances. Vaping may also affect those nearby, especially in enclosed spaces or individuals with respiratory conditions, allergies, or sensitivities. Use caution around children, pregnant women, and people with health conditions.

Possible Contraindications

Propylene Glycol:

•May cause side effects in people taking certain medications like disulfiram or metronidazole. Could trigger allergic reactions in those with a history of allergies, eczema, or hay fever.

allergies, eczema, or hay tever.

Glycerol:

Increases the risk of dehydration in the elderly and those already dehydrated.
Individuals with diabetes should use caution, as metabolized glycerol may cause minor hyperglycemia or observed.

REMINDER:
If Flare HI5 is accidentally dropped, please make sure you check the following items before using it again:
•The device is intact and no parts are loose;
•No leakage of e-juice is found on the device;
•The mouth

- If a visual inspection shows no signs of damage, you may proceed to use the device. Before use, clean the mouthpiece and other accessible parts with a dry cloth or

The vapor product system shall not be used if cracked or deformed. Using a damaged product can cause leaks, malfunctions, or explosions. Always inspect the device and battery for damage before use. If any damage is found, discontinue use immediately and replace the defective item.

Do not use the electronic cigarette if the tank is empty or nearly empty, or if you detect a significant change in

TROUBLESHOOTING:

Common Issues and Solutions

Common Issues and Solutions

No Vapor Production: Ensure the device is fully charged. If the issue persists, the device may need to be replaced.

Burnt Taste: The device may be running low on e-liquid or the internal coil could be damaged. Consider replacing the device if the problem continues.

Leaking: Make sure the device is not exposed to high temperatures or direct sunlight. If leaking persists, it may be time to replace the device.

FREQUENTLY ASKED QUESTIONS

FREQUENTLY ASKED QUESTORNO
How long can a device last?
•The Flare HI5 has a validity period of 24 months.
Replace the device when it is empty, nearly empty, or if
you notice a significant change in flavor, Regular
replacement of the device is essential to ensure optimal

Please check the manufacturing date on the product you purchased and do not use it if it has exceeded its validity

period.

Can I refill the device?

No, devices are designed for single use and should be replaced when they are empty.

Is it rechargeable? How do I know when the device is fully charged?

Yes, when the battery is fully charged, 100% will be displayed on the device screen.

FOR EXPORT TO THE PHILIPPINES:

TAX AND DUTY PAID

NO ACCESSORIES INCLUDED.

CUSTOMER SUPPORT: For any issues or questions, contact our customer support team at pacific@apexcorp.online or call (02) 8463-2480.

Thank you for choosing Flare, Enjoy your vaping experience responsibly